


DLA-24D3/R

Connection to bluelog Neo



DLA-24D3/R: Sensor and data logger connection

Description	
1	Data logger terminal, multi-input
2	DLA-24D3/R overvoltage protection (OVP)
Note In all mc Cabinets, the OVP is installed upside down.	
3	Sensor

Connection

Sensor	→ DLA-24D3/R in	→ DLA-24D3/R out	→ bluelog Neo
Signal GND	2a	2b	GND
Signal	1a	1b	MI

Item numbers

Sensor	Item nos.
DLA-24D3/R	201.151